Report

- Briefly explain your method in each step
 - Camera calibration使用助教的 sample code 執行 calibration
 - Feature Matching使用 ORB 為 feature extractor使用 opency 的 Matcher.match()來得到最好的 matches
 - Pose from Epipolar Geometry (pseudo codes and comments)
 利用前後影像當作一個 pair,將每個 pair 做特徵點的配對並計算
 Essential matrix,分解後得到 relative pose,scale 的問題是將前一個
 pair 的 descriptor 記錄下來,並與目前 pair 的 match 最配對,尋找同時
 在三張影像都出現的點,來計算 relative scale,實驗結果是 scale 有時
 會不穩定,透過設定 scale 控制在 0 到 3 之間效果較好。

Pseudo code:

```
def process_frames(self, queue):
   first_time = True
    for frame_path in self.frame_paths[1:]:
        img = cv.imread(frame_path) # read img k+1
       img_query = cv.imread(self.frame_paths[self.frame_paths.index(frame_path)-1]) # read img k
       # TODO: compute camera pose here
       orb = cv.ORB create()
        if(first_time == True):
           Omit the same process in else block
            only compute and record the \boldsymbol{X} and Pose of the first pair
           P is projection matrix of the first pair
           # calculate X
           self.last_X = compute_X()
           record_pose()
            # finish first pair
            first_time = False
            kp1, des1 = orb.detectAndCompute(img_query, None)
            kp2, des2 = orb.detectAndCompute(img, None)
           matches = match_img(des1,des2)
            points1 = get_points_from_match(kp1, matches)
            points2 = get_points_from_match(kp2, matches)
            points1 = cv.undistortPoints(points1, self.K, self.dist, None, self.K)
            points2 = cv.undistortPoints(points2, self.K, self.dist, None, self.K)
            E, _ = cv.findEssentialMat(points1, points2, self.K)
```

```
_, R, t, inlier = cv.recoverPose(E, points1, points2, self.K)
   matches = match_img(self.des_last_pair, des2)
   points_img1 = get_points_from_match(matches)
   points_img2 = get_points_from_match(matches)
   last_X = get_corresponding_points(matches)
    index_inlier = np.argwhere(inlier.flatten()).flatten()
    points1_inlier = points1[index_inlier]
   points2_inlier = points2[index_inlier]
   des2 = des2[index_inlier]
   R,t=compute_pose(R,t)
   P = np.hstack((R, t))
   X = compute_X(self.P, P, points_img1, points_img2)
   scale = relative_scale(X, last_X, R, t)
   scale %= 3
   R,t = compute_pose_with_scale(scale)
   P = np.hstack((R, t))
   self.des_last_pair = des2
   self.last_X = compute_X(self.P, P, points1_inlier, points2_inlier)
   record_pose()
queue.put((R, t))
```

Results Visualization

按照算出來的 pose 依序與原始設定的起始位置之影像平面座標相乘,來還原 pose 的世界座標,並利用 Open3D 將還原的四個點與鏡心連線,再畫在顯示視窗中。

- Youtube link
 - O Your video should be like the video shown in page 13 https://youtu.be/Q11DWFpI7VI
- Please tell us how to execute your codes, including the package used and the environment

```
Environment: Python 3.9
使用下列 package
open3d, numpy, opencv, sys, os, argparse, glob, multiprocessing
How to execute:
$ python .\camera_calibration.py .\calib_video.avi — show
$ python .\vo.py .\frames
```